

# Print Server DYMO<sup>&reg;</sup> LabelWriter<sup>&trade;</sup>

The Print Server is an easy-to-set-up network adapter that allows a LabelWriter<sup>&trade;</sup> label printer to be integrated into the computer network. Any workstation in the network can send print jobs wirelessly to a label printer after installing the software.

-Easy installation: connect the Print Server to the LabelWriter<sup>&trade;</sup> label printer (USB) and the network (Ethernet)

-Compatible with Windows<sup>&reg;</sup> and Mac<sup>&reg;</sup> operating systems

## System requirements:

-Windows<sup>&reg;</sup> XP (32 bit), Windows<sup>&reg;</sup> Vista<sup>&trade;</sup>,  
Windows<sup>&reg;</sup> 7

-Mac OS<sup>&reg;</sup> v10.3.9 or higher (LabelWriter<sup>&trade;</sup> Duo requires 10.5 or higher)

For: LabelWriter<sup>&trade;</sup> 450 Twin Turbo, 450 Duo

Description	Width mm	Depth mm	Height mm	Dimensions (WxDxH)	PK	Cat. No.
Print Server	78	59	22	78 x 59 x 22 mm	1	4.687 658