

Online data logger testo 160 E

Online data logger with two connections for external sensors for automated monitoring of temperature, humidity, LUX and UV. Measurement values are recorded and sent directly to the testo Saveris Cloud via an existing WLAN connection. In the cloud, data loggers can be configured, limit value alarms can be set and measurement data can be viewed and analysed. Thanks to the option of connecting to the testo Smart App, all measurement values can also be called up at any time and from anywhere using an internet-enabled smartphone, tablet or PC.

- Data transmission via WLAN
- Automatic measurement value documentation in testo Saveris Cloud
- Alerting if limit values are exceeded via email, SMS or push notification (testo Smart App)
- Visual inspection on site thanks to large display
- Memory for 32000 measured values

To operate the online data logger in the testo Saveris Cloud, a valid licence (subject to a charge) must be booked (Data Monitoring Licence).

Measuring ranges depend on the sensor used. Please order sensors separately.

Scope of supply: Online data logger, wall bracket, USB interface cable, 4 x AAA batteries, 2 x QR code sticker, test protocol

Dimensions (WxDxH): 76 x 64 x 22 mm
Weight: 96 g
IP code: IP 20

Type	Min. measuring cycle min	Max. measuring cycle h	Measuring cycle	Width mm	Depth mm	Height mm	Type of auxiliary energy
testo 160 E	1	24	1 min ... 24 h	76	64	22	Battery/mains connection

Zubehör:
Temperature and humidity sensor with with plug-in cable / Testo SE & CO KGaA